

## A

- allowed list, VLAN 2-28 to 2-29
- ATM 2-5
  - firmware upgrade B-5 to B-7
  - LANE trunk connections 1-4
  - module 2-9, 2-13, 2-23
  - networks 2-5
  - trunk 2-4, 2-14

## B

- bridge groups 3-15
- bridge number 2-10
- Bridge Priority parameter 2-47
- bridge-router between VLANs A-5
- bridging protocols A-5
- broadcast domain 2-3

## C

- Catalyst switch models 1-2
- characteristics, VLAN 2-9
- commands
  - configuration file upload/download 3-22
  - Fast EtherChannel 3-9
  - TACACS+ 3-19
- configuration file 3-22
  - default values 1-6
  - download commands 3-22
  - download example 3-23
  - limitations 3-21
  - retrieving automatically 3-21
  - upload example 3-23
  - uploading to TFTP server 3-22

## D

- defaults
  - Enterprise Edition software settings (table) 1-6
  - VLAN features (table) 2-4
- deleting
  - pruning-eligible VLANs 2-31
  - VLANs, from allowed list 2-29
- DHCP
- DISL 1-4, 2-23
  - and bridge groups 2-23
  - port states 2-24
  - status of ports 2-25
- displaying VLAN traffic 2-31
- document conventions ix
- downloading a configuration file 3-22
- duplicate MAC address handling A-7
- Dynamic Host Configuration Protocol, see DHCP
- Dynamic Inter-Switch Link Protocol
  - see DISL 1-4
- dynamic ports
  - configuring 2-43
  - on VMPS clients 2-41

## E

- ELANs 2-5

## F

- Fast EtherChannel 3-1
  - active link 3-5
  - addresses
    - adding 3-6
    - deleting 3-6
  - and bridge groups 3-1

- CGMP Configuration Menu 3-7
- commands 3-9
- configuring 3-6, 3-7
- default values 1-6
- DISL state 3-7
- distribution, source-based 3-4
- example 3-9
- flooding traffic 3-5
- frame order, preserving 3-4
- known unicast traffic 3-5
- Multicast Registration Menu 3-7
- packet forwarding 3-5
- PAgP 3-2
- Port Addressing Menu 3-7
- template port, using 3-3
- trunking 3-11
- verifying configuration 3-8
- Fast Ethernet
  - port 2-13
  - routers 2-5
  - switches 2-5
- FDDI firmware upgrade B-5 to B-7
- FDDI VLAN 2-10
- firmware
  - module
    - upgrade from an TFTP client B-6
    - upgrade from TFTP server B-5
    - upgrade using XMODEM protocol B-7
  - switch
    - upgrade from TFTP client B-3
    - upgrade from TFTP server B-3
    - upgrade from XMODEM Protocol B-4
- Firmware Configuration Menu B-1
- flooded traffic
  - and VTP 2-36
  - displaying 2-31
- Forward Delay parameter 2-47

## H

- Hello Time parameter 2-47
- hub manager
  - online help x, xi

## I

- Inter-Switch Link 2-4
- ISL trunks 1-4, 2-4, 2-13

## L

- LAN emulation 1-4
- LANE ATM trunk connections 1-4
- lists, pruning-eligible VLAN 2-31
- load balancing 3-4
- load sharing 1-4
  - between redundant links 2-18
  - capability 2-4
  - default value 2-4
  - using path costs 2-18
  - using port priorities 2-15
  - using port priority 2-17

## M

- MAC-level spoofing A-3
- Main Menu 1-9
- management console 1-6
- management domains, assigning 2-9
- Max Age parameter 2-47
- maximum transmission unit (MTU) 2-10
- menus
  - CGMP Configuration Menu 3-7
  - Main Menu 1-9

- Multicast Registration Menu 3-7
- Port Addressing Menu 3-7
- STP Menu 2-45
- User Interface Menu 1-8
- Virtual LAN Menu 2-7

module

- upgrade firmware from TFTP server B-5
- upgrade firmware from XMODEM Protocol B-7

## P

PAgP

- channel modes 3-2
- enabling or disabling 3-4
- parameters 2-47
- password, configuring 2-35
- path cost, STP 2-18
- physical learner device 3-4
- port
  - assignment to VLAN 2-1
  - grouping 2-11, 2-12
  - priority 2-17
  - see also dynamic ports 2-17
- Port Aggregation Protocol
  - see PAgP
- pruning-eligible VLAN 2-30, 2-31
- publications, related x

## R

- related publications x
- ring number 2-10

## S

- security association identifier 2-10

- security, network 2-3
- software features 1-3
- source-based distribution 3-4
- Spanning-Tree Protocol
  - see STP
- static addresses A-7
- STP
  - assigning an instance 2-48
  - capability 2-4
  - configuring 2-45
  - default value 2-4
  - enabling and disabling 2-45
  - options 2-47
  - parameters 2-47
  - path costs 2-18
  - type 2-10
  - UplinkFast 3-11, 3-13, 3-14
  - verifying configuration 2-46
- switch operation
  - Main Menu 1-9
  - management console 1-6
  - User Interface Menu 1-8
- switches 1-1, 1-3

## T

TACACS+ 3-16

- authentication tasks 3-16
- commands 3-19
- configuring 3-19
- default values 1-6
- example 3-20

tagging 2-5

TFTP client

- downloading module firmware B-6
- upgrade switch firmware B-3

TFTP server 3-21, 3-22

- example 3-23
- upgrade switch firmware B-3

- Token Ring VLAN 2-10
- traffic control 2-3
- translational bridge 2-10
- transport protocols 2-5
- trunk-port connections A-7
- trunks
  - ATM 2-14
  - configuring 2-27
  - connection types 2-34
  - ISL 1-4, 2-4, 2-13
  - priorities, assigning 2-16

## U

- upgrading firmware
  - FDDI or ATM B-5 to B-7, ?? to B-7
  - modules B-5 to B-7, ?? to B-7, ?? to B-7
  - switch B-2 to B-4
- UplinkFast 3-11
  - configuring 3-13
  - web console parameters 3-14
- upload commands 3-22
- User Interface Menu 1-8

## V

- virtual LAN
  - see VLAN
- VLAN 1-3
  - adding pruning-eligible 2-30
  - adding to allowed list 2-28
  - address learning A-3
  - address resolution example A-3
  - addressing 2-3
  - administrative action A-1
  - and ARP cache entries A-3
  - and broadcast frames A-3
  - assigning ports 2-1

- characteristics 2-9
- components 2-5
- configuration examples A-1
- configuration steps 2-6
- cut-through example A-1
- default values 1-6
- defining a, 2-10
- deleting from allowed list 2-29
- displaying 2-31
- dynamic port VLAN membership 2-39, 2-42
  - configuring 2-42
- effects of changes A-3
- FDDI 2-10
- features 2-1
  - differences from other Cisco products A-1
- interaction with bridge groups 3-15
- isolation
  - limited A-1
  - MAC-level spoofing A-3
- management domain 2-9
- mapping 2-5
- membership 1-4, 2-4
- Membership Policy Server
  - see VMPS
- parent 2-10
- port grouping defaults 2-12
- ports, assigning 2-1
- single MAC address support A-5
- Token Ring 2-10
- trunk configuration 2-23, 2-27
- trunks 1-4, 2-13, 2-17

- VLAN Trunk Protocol
  - see VTP 2-32
- VMPS 2-40
  - capability 2-4
  - configuring 2-43
  - default value 2-4
- VTP 1-4, 2-32
  - advertisements 2-34
  - capability 2-4
  - configuring 2-34

default value 2-4  
in information propagation 2-23  
modes 2-8, 2-32 to 2-33  
password 2-35  
pruning 1-4  
VTP pruning 2-35  
    capability 2-4  
    configuring 2-35  
    default value 2-4  
    enabling 2-37

## **W**

web console  
    Fast EtherChannel configuration 3-10  
    UplinkFast configuration 3-14

## **X**

XMODEM protocol  
    upgrade switch firmware B-4

